

PRODUCT USE GUIDE FOR LIFT GRAFFITI REMOVER GR4

Product Description

Developed using the lowest hazard and a low-odour formula. Effectively removes a wide range of graffiti from a wide range of surfaces.

Product Features

- A low odour emulsifiable graffiti remover.
- Removes aerosol spray, marker pen and ballpoint from stone, plastic, brickwork and paintwork.

Direction for Use

- Apply product to surface.
- Leave to activate for 3-5 minutes.
- Use power washer to remove or scrub manually with stiff bristle brush, then rinse.

Storage

- Store in cool conditions away from direct sources of heat
- Avoid extremes of temperature
- Do not allow to freeze
- Ensure the cap is tightly fitted after use
- Keep out of reach of children

Shelf Life

- Shelf life 24 months, if stored as recommended.
- Use within 6 months of opening.

Environmental

- Do not allow large quantities of neat liquid to enter surface waterways.
- In the event of a large spillage, contact the local water authority or Environment Agency immediately.
- This product uses recyclable packaging. The detergents used in the formulation are biodegradable to EU guidelines under the detergents regulations (EC) No 648/2004.
- It contains no Phosphates.









PRODUCT USE GUIDE FOR LIFT GRAFFITI REMOVER GR4

For further information, please scan your smart phone QR reader here



Code Nos.

057666 6x750ml

Data Sheet No. GR4

Note: This product is only to be used for the purpose for which it was intended and in accordance with the specified instructions. This product should never be mixed with other chemical products and should be handled with care and stored carefully out of reach of children.



Cleenol Group Ltd

Beaumont Road, Banbury, Oxon, OX16 1RB. UK. Tel: +44 (0) 1295 251721 Fax: +44 (0) 1295 269561 Email: sales@cleenol.co.uk www.cleenol.co.uk

Certificate No. 316

